

Thermo Scientific Model 5014*i* Beta Continuous Particulate Monitor

Automated ambient particulate measurement utilizing beta attenuation

The Thermo Scientific™ Model 5014*i* Beta Continuous Particulate Monitor uses beta attenuation technology in combination with the established *i*Series platform design.

- U.S. EPA Approved PM-10 (EQPM1102-150) and PM-2.5 (EQPM0609-183) equivalent monitor
- Continuous, non-stepwise measurement
- Volatile loss mitigation via Dynamic Heating System
- Long term, unattended operation
- Low detection limit, high accuracy and resolution
- Enhanced user interface and *i*Port communication software



A known volume of air is drawn through a size-selective inlet, which can be configured to measure PM-10, PM-2.5, PM-1 or TSP, and deposited onto the auto-advancing filter tape. The combined measurement of mass and air volume are used to obtain the mass concentration readings. Supplied with user-selectable data logging options, concentrations can be reported in actual or standard conditions.

The Model 5014*i* monitor auto-advances the particulate-laden sample filter in accordance with user-defined parameters such as mass accumulation limits, timed intervals or the continuous flow rate relative to pressure changes.

The filter tape will advance in a continuous pattern, as compared to stepwise measurement, resulting in the mitigation of particle losses. In addition, the filter tape will advance if the sample exceeds maximum loading criteria.

To accurately address potential water bias and volatile loss, the Dynamic Heating System allows the user to hold the sample temperature at a fixed value or below a relative humidity threshold.

This state-of-the-art monitor also features:

- Flash memory for increased data storage
- Enhanced Ethernet connectivity
- Remote data access



Thermo Scientific Model 5014i Beta Continuous Particulate Monitor

Source	Carbon-14 (C-14), < 3.7 MBq (< 100 µCi)
Measurement Range	0 to 1.0, 2.0, 3.0, 5.0, 10.0 mg/m ³ ; 0 to 100, 1,000, 2,000, 3,000, 5,000, 10,000 µg/m ³
Minimum Detection Limit	6 µg/m ³ (1/2 hour), 4 µg/m ³ (1hour); 3 µg/m ³ (3 hour), 1 µg/m ³ (24-hour)
Resolution	0.1 µg/m ³
Precision	±2.0 µg/m ³ < 80 µg/m ³ , 4-5 µg/m ³ > 80 µg/m ³ (24-hour average)
Accuracy (for mass measurement)	± 5% using NIST-traceable mass foil set
Air Flow Rate	1m ³ /h (16.67L/min) measured across an internal subsonic orifice
Sample Flow Precision	±2% of measured value
Sample Flow Accuracy	< 5% of measured value
Mass Concentration	60 to 3,600 seconds and 24-hour
Data Output Rate	Every 1 second
Operating Temperature	The temperature of sampled air may vary -30° to 50°C. 5014i must be weather protected within range 4° to 50°C An optional Complete Outdoor Enclosure provides complete weather protection
Non-condensing	< 95% RH inside 5014i Monitor
Output	RS232/RS485, TCP/IP, 10 Status relays and power fail indication (standard). 6 user defined analog outputs (0-100mV, 0-1, 0-5 or 0-10 Vdc), Six 0-20 or 4-20 mA isolated current output (optional)
Input	16 Digital inputs (standard), Eight 0 to 10 Vdc Analog inputs (optional), 8 User-defined Analog ; outputs (0-1 or 0-5 Vdc)
Power Requirements	100 - 240 VAC, 50-60 Hz Recommended; 805 Watts (115V); 880 Watts (220-240V) Watts Maximum (instrument, heater & pump)
Pump	120 VAC/60 Hz: 4.25A; 240 VAC/50Hz:2.25A
Physical Dimensions	16.75" (42.5cm) W x 23" (58.4cm) D x 8.62 (21.9cm) H; 19" rack mountable with optional ears and handles
Weight	40 lbs. (19kg)
Protocols	C-Link, MODBUS TCP/IP, Gesytec (Bayern-Hessen), ESM Protocol, Streaming data and NTP (Network Time Protocol) protocols. Simultaneous connections from different locations over Ethernet
Safety and Electrical Designations	Designed to meet CE: EN61326:1997 + A1:1998 + A2:2001 + A3:2003, EN61010-1 UL: 61010-1:2004; CSA: C22.2 No. 61010-1:2004; FCC: Part 15 Subpart B, Class B
Approvals and Certifications	U.S. EPA PM-10 Equivalent Monitor: EQPM1102-150; U.S. EPA PM-2.5 Equivalent Monitor: EQPM0609-183

Ordering Information

Model 5014i Beta

Choose from the following configurations/options to customize your own Model 5014i Beta

1. Voltage options:

A = 110 VAC 50/60 Hz
B = 220 VAC 50/60 Hz
D = 220 VAC 50/60 Hz (with China power cord)

2. Tube options:

H = Extended tube assembly (6')
Includes SS tube union and teflon ferrule
N = No extended tube assembly
T = Tripod
B = Tripod & extended tube assembly (6')
Includes SS tube union and teflon ferrule

3. Inlet options:

C = TSP with bug screen
E = PM-10 USEPA
T = PM-10 Traditional
S = SCC inlet combo (PM-10 USEPA, 1st stage w/ PM-2.5 SCC)
U = SCC inlet combo (PM-10 Traditional, 1st stage w/ PM-2.5 SCC)
V = VSCC inlet combo (PM-10 USEPA, 1st stage w/ PM-2.5 VSCC)
W = VSCC inlet combo (PM-10 traditional, 1st stage w/ PM-2.5 VSCC)
1 = SCC inlet combo (PM-10 USEPA, 1st stage w/ PM-1 SCC)
2 = SCC Inlet Combo (PM-10 Traditional, 1st stage w/ PM-1 SCC)
3 = PM-10 Inlet (EU-style DPM10/01/00), 1 m³/h
4 = PM-2.5 Inlet (EU-style DPM 25/01/00), 1 m³/h
N = No inlet

4. Optional I/O:

A = None (standard)

C = I/O expansion board
4-20mA outputs - 6 channels,
0-10V inputs - 8 channels

5. Mounting Hardware:

A = Bench mounting (standard)
B = Ears & handles, EIA (optional)
C = Ears & handles, Retrofit

Included:

- Heated sample tube (1m)
- Sample pump (Universal)

Your Order Code: Model 5014i - _ _ _ _ _

To maintain optimal product performance, you need immediate access to experts worldwide, as well as priority status when your air quality equipment needs repair or replacement. We offer comprehensive, flexible support solutions for all phases of the product life cycle. Through predictable, fixed-cost pricing, our services help protect the return on investment and total cost of ownership of your Thermo Scientific products.

For more information, visit our website at thermoscientific.com/air

© 2013 Thermo Fisher Scientific Inc. All rights reserved. All trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries. Specifications, terms and pricing are subject to change. Not all products are available in all countries. Please consult your local sales representative for details.

This product is manufactured in a plant whose quality management system is ISO 9001 certified.

USA 27 Forge Parkway Franklin, MA 02038 Ph: (866) 282-0430 Fax: (508) 520-1460 customerservice.aqi@thermofisher.com	India C/327, TTC Industrial Area MIDC Pawane New Mumbai 400 705, India Ph: +91 22 4157 8800 india@thermofisher.com	China +Units 702-715, 7th Floor Tower West, Yonghe Beijing, China 100007 +86 10 84193588 info.eid.china@thermofisher.com	Europe Takkebijsters 1 Breda Netherlands 4801EB +31 765795641 info.aq.breda@thermofisher.com
---	--	---	---

Thermo
SCIENTIFIC

Part of Thermo Fisher Scientific